


attaching push to open hinge to doors



step 2


hardware key

A	B	C	D	E
				
push to open hinges x 20	4.5 x 16mm wood screws x 80	push to open mechanism x 10	adhesive catch plate x 10	3.5 x 16mm wood screws x 40



1. removing hinge plate


Remove the hinge from the hinge plate by pushing on the release tab.



5. attaching self adhesive plate to push to open mechanism

Attach self adhesive plate to magnet on push to open mechanism.


Peel self adhesive cover from plate.



2. attaching hinge plate to cabinet

attach with screws through the elongated holes.


Note: if plastic lugs not in pre-drilled holes, fix into place carefully using a hammer first.



6. attaching self adhesive plate to cabinet door

Close door and hold for 10 seconds. While holding door closed, apply pressure to location of the push to open mechanism.


Open door and check shelf adhesive plate has transferred to door. Repeat step if transfer has not occurred.



3. attaching hinge to door


attach with screws.

Note: if plastic lugs not in pre-drilled holes, fix into place carefully using a hammer first.



4. attaching push to open mechanism to cabinet

base cabinet: Install the mechanism on the top rail of the cabinet on the opposite side to where you placed the hinges.
wall cabinet: Install the mechanism on the bottom shelf of the cabinet on the opposite side to where you placed the hinges.
pantry: Install the mechanism on the middle shelf of the pantry on the opposite side to where you placed the hinges.



Mechanism should be placed flush with the front of rail/shelf as shown above. Mark and Pre-drill before installing.

step 1	✓ step 2	✓ step 3	step 4
Your cabinets are now assembled.	You've installed your parts and accessories.	Then follow the instructions to fit your doors and panels.	Finish off your Kaboodle Kitchen by installing your benchtop.

Caring for your Kaboodle parts and accessories

Looking after your parts and accessories is really easy and with the right care and maintenance they will last you for many years. Just follow these simple steps.

Hinges, runners and other parts and accessories should be kept dry at all times. To keep the mechanisms performing at their best, regularly wipe them with a dry cloth removing any dust and grime that may build up. In case of spills, clean immediately with a dry cloth. Do not use harsh abrasives.

If you need any more information you can contact us:
 Australia: **1800 666 078** Monday to Friday between 8:00am and 6:00pm AEST.
 New Zealand: **0800 522 663** Monday to Friday between 8:00am and 5:00pm NZST
 or email: info@kaboodlegroup.com.au.

*Conditions for Lifetime Warranty: www.kaboodlegroup.com.au

* The benefits given by this express warranty are additional to other rights and remedies that you may have under law. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and or compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.